





# pt 107 / hms 1070



Skizze	Art.Nr.	Benennung	description
1	390 2204 011		
2	390 2204 012		
3	390 2204 013		
4	390 2204 014		
5	390 2204 015		
6	390 2204 016		
7	390 2204 017		
8	390 2204 018		
9	390 2204 019		
10	390 2204 020		
11	390 2204 021		
12	390 2204 022		
13	390 2204 023		
14	390 2204 024		
15	390 2204 025		
16	390 2204 026		
17	390 2204 027		
18	390 2204 028		
19	390 2204 029		
20	390 2204 030		
21	390 2204 031		
22	390 2204 032		
23	390 2204 033		
24	390 2204 034	Drehgriff	handle knob
25	390 2204 035		
26	390 2204 036		
27	390 2204 037		
28	390 2204 038		
29	390 2204 039		
30	390 2204 040		
31	390 2204 041		
32	390 2204 042		
33	390 2204 043		
34	390 2204 044		
35	390 2204 045		
36	390 2204 046		
37	390 2204 047	Skala	scale
38	390 2204 048		
39	390 2204 049		
40	390 2204 050		
41	390 2204 051		
42	390 2204 052		
43	390 2204 053		
44	390 2204 054		
45	390 2204 055		
46	390 2204 056	Feststellgriff	locking knob
47	390 2204 057		
48	390 2204 058		
49	390 2204 059	Drehgriff	handle knob
50	390 2204 060		
51	390 2204 061		
52	390 2204 062		
53	390 2204 063		
54	390 2204 064		
55	390 2204 065		
56	390 2204 066		
57	390 2204 701	Hobelmesser	planer knife
58	390 2204 067	Feder	spring
59	390 2204 068	Gewindestift	threaded pin
60	390 2204 069	Klemmleiste	terminal strip
61	390 2204 070	Schraube	screw
62	390 2204 071		
63	390 2204 072		
64	390 2204 073		

# pt 107 / hms 1070



Skizze	Art.Nr.	Benennung	description
65	390 2204 074		
66	390 2204 075		
67	390 2204 076		
68	390 2204 077		
69	390 2204 078		
70	390 2204 079		
71	390 2204 080		
72	390 2204 081		
73	390 2204 082		
74	390 2204 083		
75	390 2204 084		
76	390 2204 085		
77	390 2204 086		
78	390 2204 087		
79	390 2204 088		
80	390 2204 089		
81	390 2204 090		
82	390 2204 091		
83	390 2204 092		
84	390 2204 093		
85	390 2204 094		
86	390 2204 095		
87	390 2204 096	Zeiger	pointer
88	390 2204 097	Skala	scale
89	390 2204 098		
90	390 2204 099	Drehknopf	handle knob
91	390 2204 100	Gewindestange	adjustable rod
92	390 2204 101		
93	390 2204 102	Antriebsstange	driving rod
94	390 2204 103		
95	390 2204 104	Kappe	cap
96	390 2204 105		
97	390 2204 106		
98	390 2204 107		
99	390 2204 108		
100	390 2204 109		
101	390 2204 110	Drehknopf	handle knob
102	390 2204 111	Hobelwellenschutz	planer shaft guard
103	390 2204 112		
104	390 2204 113		
105	390 2204 114		
106	390 2204 115		
107	390 2204 116		
108	390 2204 117		
109	390 2204 118		
110	390 2204 119		
111	390 2204 120		
112	390 2204 121		
113	390 2204 122		
114	390 2204 123		
115	390 2204 124		
116	390 2204 125		
117	390 2204 126		
118	390 2204 127	Endschalter	micro switch
119	390 2204 128		
120	390 2204 129	Keilriemen	v-belt
121	390 2204 130		
122	390 2204 131	Riemenscheibe	pulley
123	390 2204 132		
124	390 2204 133	Kette	chain
125	390 2204 134	Antriebsrad	pinion
126	390 2204 135	Riemenscheibe	pulley
127	390 2204 136		
128	390 2204 137		

# pt 107 / hms 1070



Skizze	Art.Nr.	Benennung	description
129	390 2204 138	Rippenband	ripped v-belt
130	390 2204 139		
131	390 2204 140	Schutzabdeckung	protecting hood
132	390 2204 141		
133	390 2204 142		
134	390 2204 143		
135	390 2204 144	Kettenrad	chain wheel
136	390 2204 145	Buchse	sleeve
137	390 2204 146	Zahnrad	gear wheel
138	390 2204 147		
139	390 2204 148	Feder	spring
140	390 2204 149		
141	390 2204 150		
142	390 2204 151		
143	390 2204 152		
144	390 2204 153		
145	390 2204 154		
146	390 2204 155		
147	390 2204 156		
148	390 2204 157		
149	390 2204 158		
150	390 2204 159		
151	390 2204 160		
152	390 2204 161		
153	390 2204 162		
154	390 2204 163		
155	390 2204 164		
156	390 2204 165		
157	390 2204 166		
158	390 2204 167	Überlastschalter	overload switch
159	390 2204 168		
160	390 2204 169		
161	390 2204 170		
162	390 2204 171	Schalter	switch
163	390 2204 172		
164	390 2204 173		
165	390 2204 174		
166	390 2204 175		
167	390 2204 176		
168	390 2204 177		
169	390 2204 178	Kohlebürsten (Satz = 2 Stück)	carbon brushes (set = 2 pcs.)
170	390 2204 179		
171	390 2204 180		
172	390 2204 181		
173	390 2204 182		
174	390 2204 183		
175	390 2204 184		
176	390 2204 185		
177	390 2204 186		
178	390 2204 187		
179	390 2204 188		
180	390 2204 189		
181	390 2204 190		
182	390 2204 191		
6, 33, 89, 165, 180	390 2204 010	Motor kpl.	motor cpl.
63, 68, 83-86	390 2204 192	Absaughaube kpl.	suction hood cpl.
27-28, 31, 44-46, 65-82	390 2204 193	Anschlag kpl.	fence cpl.
39, 49, 74, 95-106, 181-182	390 2204 194	Hobelwellenschutz kpl.	planer shaft guard cpl.
	390 2204 195	Einstellehre	adjusting gauge